



**FLAT TRACK END STOP**

PART No. 0105.00110



**Application:** The End Stop is used on each end of the Flat Track to stop the door hangers from falling off the ends of the track.

2 End Stops are needed for each track.

**Finish:** Black powder coat

**RICHARDS-WILCOX**

600 S. Lake St. Aurora, IL 60506  
800-253-5668 • (630) 897-6951  
richardswilcox.com

## DESCRIPTION:

## FLAT TRACK END STOP

Part No.:

0105.00110

Date:

6/12/07

Part Weight:

0.312

Rev.:

C

**NOTICE:**

THIS DRAWING IN DESIGN AND DETAIL IS  
THE PROPERTY OF RICHARDS-WILCOX. ANY  
REPRODUCTIONS OF THIS PRINT AND/OR  
DESIGN WITHOUT THE WRITTEN CONSENT OF  
RICHARDS-WILCOX IS PROHIBITED.